





Electrolux

Ease C2




1


* Certain models only | Suivant les modèles | فقط بعض الموديلات | Само определенные модели | Pouze u některých modelů | Nur bestimmte Modelle
Kun på visse modeller | Ainult kindlad mudelid | Solo algunos modelos | فقط برای بعضی مدلها | Vain tietyt mallit | Ορισμένα μόνο μοντέλα
Samo određeni modeli | Csak egyes típusoknál | Solo per alcuni modelli | Tik tam tīkriems modeļi | Tikai noteiktiem modeliem | Kun enkelte modeller
Tylko niektóre modele | Doar pentru anumite modele | Только отдельные модели | Bara vissa modeller | Le določeni modeli | Len určité modely
Само код одређених модела | Yalnızca bazı modellerde | Залежно від моделі





2



3




4




5


R Recommended nozzle | Brosse recommandée | الفوهة الموصى بها | Препоръчителна дюза | Doporučená hubice | Empfohlene Düse | Anbefalet mundstykke
Soovituslik otsak | Cepillo recomendado | نازلہای توصیه شده | Suositeltava suulake | Συνιστώμενο ακροφύσιο | Preporučeni nastavak | Ajánlott szívófej
Spazzola consigliata | Rekomenduojamas antgalis | Leteicams uzgalis | Anbefalt munnstykke | Zalecana dysza | Perie recomandată | Рекомендованная насадка
Rekommenderat munstykke | Priporočni nastavek | Odporúčaná hubica | Препоручени наставка | Önerilen başlık | Рекомендована насадка




6



7



8



9



www.electrolux.com/shop